

INSTALLATION INSTRUCTIONS

MULTI PURPOSE COVER PLATE

Suitable for Washing Machines & Dishwashers

Covers a hole in the cupboard up to 120mm x 115mm

Can be retrofitted

FOR USE ON A WASHING MACHINE INSTALLATION

- Cut a hole in the cupboard large enough to bring through all services
- 2 Slide the bottom plate over the hot and cold hoses and the power cord
- **3** Remove the white cap and bring the outlet (waste) hose through the larger hole
- **4** Position the plate so that the hole in the cupboard is covered
- **5** Fit the top plate, locking the pipe work in the holes
- 6 Secure with screws









FOR USE ON A DISHWASHER INSTALLATION

As per above but leave the white cap in place.



